COLDNet Profile – Importing Geo-referenced Images

Geo-referenced image files can be imported at any stage during the design process by selecting **Tools>Background Imagines** the following window will open.



Select **Load Images** and navigate to where your GIS files are saved and load the files as shown below.



Once the geo-referenced files have been imported the varies images can be turned off and on. Exit the form to load the GIS imagery as shown below.


File
Design Parameters & Libraries
Terrain Data
Profiles
Conductors
Tables
Tools
Feature Codes
Reports
Clone Design
Plots
Export
Undo
Clear Undo/Redo Lists
Job History
Add Offline Point
Cross-Sections
3D View
COGO
Guide
Information
Calculators
Current Design
View
Ground Points
Points
Comments
Point Numbers
Poles
Sequence Numbers
Asset Numbers
Details
Conductors
Wires
Blowout
Blowout Settings
Measure
Show Triangles
Find
Point Management
Mouse Locked
Colorise Ground Points
Fill Triangles
5280.00m
What do I do?
Last Saved at :14:49